

IMPORTANT

This document is intended for use by authorized Nokia service centers only. Please use the document together with other documents such as the Service Manual and Service Bulletins.

Version information

While every effort has been made to ensure that the document is accurate, some errors may exist. Please always check for the latest published version for this document.

If you find any errors in the document please send email to: [service.manuals@nokia.com](mailto:service.manuals@nokia.com)

Version history

- 1.0 First Approved version.
- 2.0 Corrected J2000 connection

Copyright © Nokia  
This material,including documentation and any related computer programs is protected by copyright, controlled by Nokia. All rights are reserved. Copy- ing, including reproducing, modifying, storing, adapting or translating any or all of this material requires the prior written consent of Nokia. This material also contains company confidential information, which may not be disclosed to others without the prior written consent of Nokia.

Service Schematics



RM-590/RM-591



Table of Contents

Front page	1
UPP, UEMCLITE, Memory, Audio, FM, UIHW	2
UIHW, Keyboard	3
RF part	4
Component Finder Top	5







